




Figure 1

RM80 General Assembly Spare Parts List(Figure 1)

No.	Item	Description	Specification	Quantity
1	800101	Countersunk square neck Bolt	M12*70	4pcs
2	800102	Flat washer	Ø12	4pcs
3	800103	Locked Nut	Ø12	4pcs
4	800104	Tamping plate	330*290	1pc
5	800105	Connecting rod pin		1pc
6	800106	Clip	Ø16	1pc
7	800107	Paper gasket	1mm	1pc
8	800108	“O” ring	110*4	1pc
9	800109	Enlarged Flat washer	Ø10*35	2pcs
10	800110	Spring washer	Ø10	14pcs
11	800111	Inner Hexagon bolt	M10*20	2pcs
12	800112	Decorating cover		1pc
13	800113	Fuel cock and fuel pipe		1pc
14	800114	Fuel tank		1pc
14	80011401	Fuel cap		
15	800115	Medium Flat washer	Ø8*24	6pcs
16	800116	Flange bolt	M8*25	2pcs
17	800117	Flange nut	M8	6pcs
18	800118	Thin thread nut	M10*1. 25	1pc
19	800119	Flange bolt	M8*20	4pcs
20	800120	Flange nut	M6	2pcs
21	800121	Throttle lever assembly		1pc
22	800122	Inner Hexagon bolt	M6*30	2pcs
23	GX120T	Engine		1set
24	800124	Key	5*28	1pc
25	800125	Clutch support drum		1pc
26	800126	Clutch assembly		1set
27	800127	Quenched Flat washer	Ø8*24	1pc
28	800128	Spring washer	Ø8	1pc
29	800129	External hexagon bolt	M8*20	1pc

30	800130	Locked nut	M8	10pcs
31	800131	Flat washer	Ø8	8pcs
32	800132	Double-end bolt	M8*40	4pcs
33	800133	bolt	M8*40	4pcs
34	800134	Protection frame		1pc
35	800135	Plastic Handle		1set
36	800136	Locked nut	M5	2pcs
37	800137	Inner Hexagon bolt	M5*16	2pcs
38	800138	Inner Hexagon bolt	M10*40	4pcs
39	800139	Inner Hexagon bolt	M10*25	4pcs
40	800140	Flat washer	Ø10	12pcs
41	800141	Double end bolt	M10*55	4pcs
42	800142	Locked nut	M10	8pcs
43	800143	Connecting flange		1pc
44	800144	bracket		1pc
45	800145	Frame absorber		2pcs

46	800146	Frame cover(right)		1pc
47	800147	junction panel		1pc
48	800148	Frame cover(left)		1pc
49	800149	Engine supporting plate		1pc
50	800150	Flat cross bolt	M8*25	2pcs
51	800151	Handle upper absorber	35*15	2pcs
52	800152	Crank Case Assembly		1pc
53	800153	Cylinder Assembly		1pc




Figure 2

RM80 Crank Case Assembly spare parts list (Figure2)

No.	Item	Description	Specification	Quantity
1	800201	Flange bolt	M6*18	6pcs
1	800201	Flange bolt	M6*25	2pcs
2	800202	Crank case cover		1pc
3	800203	Paper gasket	0.5mm	1pc
4	800204	Clip	Ø20	1pc
5	800205	Big gear		1pc
6	800206	Deep groove ball bearing	6207	1pc
7	800207	Clip	Ø62	1pc
8	800208	Deep groove ball bearing	6305-RS	1pc
9	800209	Clip	Ø25	1pc
10	800210	Crank Case		1pc
11	800211	Nylon closed cover		1pc
12	800212	Connecting rod		1pc
13	800213	Deep groove ball bearing	6204	2pcs
14	800214	clip	Ø47	1pc
15	800215	Small gear		1pc
16	800216	key	5*20	1pc
17	800217	Deep groove ball bearing	6007	1pc
18	800218	Oil seal	TC40*68*8	1pc
19	800219	Clutch support drum		1pc
20	800220	Quenched Flat washer	Ø8*24	1pc
21	800221	Spring washer	Ø8	1pc
22	800222	External hexagon bolt	M8*20	1pc




Figure 3

RM80 Cylinder Assembly(Figure3)

No.	Item	Description	specification	quantity
1	800301	Inner hexagon bolt	M10*25	4pcs
2	800302	Inner hexagon bolt	M10*45	4pcs
3	800303	Spring washer	Ø10	8pcs
4	800304	Foot plate		1pc
5	800305	“O” ring	100*4	2pcs
6	800306	Inside cylinder		1pc
7	800307	Protection sleeve		1pc
8	800308	Oil Lever gague		1pc
9	800309	Copper gasket	Ø12	1pc
10	800310	Hexagon Oil plug	M12*1. 25	1pc
11	800311	“O” ring	160*4	2pcs
12	800312	Bellow clamp		2pcs
13	800313	Bellow	Ø170	1pc
14	800314	Small spring		2pcs
15	800315	Big spring		2pcs
16	800316	Piston rod		1pc
17	800317	Piston cap		1pc
18	800318	piston rod pin		1pc
19	800319	clip	Ø16	4pcs
20	800320	Outside cylinder		1pc
21	800321	Spring column pin	5*45	1pc